
TGE BATTH CHTLLER
USER MANUAL







CAUTION - (Possible injury or property damage)


- Do not install the chiller in closets, cabinets, or other small places.
- Never cover the intake or exhaust openings with clothes, towels, or other objects.
- Use extreme caution when operating near children, the elderly or infirm.
- Never insert fingers or foreign objects into the ventilation grilles or other parts of the chiller.
- Do not place heavy objects on the power cord or run it under carpets or rugs.
- Do not climb, sit, or stand on the chiller, or place objects on top of it.
- The operators of the chiller must be at least 18 years old.

Note: At present, Tuya can only support 2.4G WiFi signal. Therefore, before connecting the phone to the chiller, please confirm that the WiFi used by your phone is in the 2.4G frequency band. It will not be able to connect to the chiller, If it is in the 5G frequency band.





No further notice will be given, if the product function is upgraded. Contact us for the latest information.





Main Technical Data Sheet

Product Name	Ice Bath Machine Parameters				
Horsepower	0.5HP	0.5HP			
Model No.	QG-RA-12	QG-RC-12			
Rated Voltage	100-127V 60Hz	220-240V 50Hz			
Input Power	530W	695W			
Compressor Power	358W	410W			
Cooling Capacity	1200W	1280W			
Heating Capacity	1500W	1650W			
Usage Environment	0~45°C				
Refrigerant	R32				
Temperature	3~42°C adjustable				
Ozone	Optional				
Circulating Pump	Buit-in Self-priming System				
Filter	6.5 inches (16.5 cm)				
Remote Control	IOS & Android APP, WIFI				
Moving Wheels	Yes				
Carry Handle	Yes				
Quick Connector	Yes				
Net Weight	28KG				
Product Size	485x300x385mm				
Water Volume &cooling Time	(25 to 3°C) 250L≥11h (Ambient temperature 28°C)	(33 to 3°C) 250L≥8h (Ambient temperature 20°C)			

Standard Machine and Accessories



Plastic Wrench



Rubber Seals



Water Pipes



Adapter



Ice Bath Chiller



PTFE Tape



Quick Conectors



Filter



Filter Elements

Quick Start Guide

Before You Begin:

- Inspect the water hoses and accessories.
- Check for O-rings at both ends of the water hoses. If missing, locate them in the accessory kit and install them.

Connecting the Chiller & Tub:

- Prepare the Tub & Accessories:
 - Your tub should either be empty for chiller setup or the water ports should be isolated with a valve.
 - Use PTFE tape to create water tight seals by wrapping it around any male threaded connections.
- Install the adapters in the tub's water ports.
- Install the strainer at the water inlet of the chiller.
- Connect one water hose to the tub's inlet and the chiller's outlet.
- Connect the second water hose to the tub's outlet and the chiller's inlet.
- Final Check: Ensure all connections are secure. Check that the hoses are not kinked or pinched to ensure proper water flow and to prevent chiller alarms.







Fill the Tub:

 Before running or testing the chiller, fill the tub with fresh water until the water is above both the water inlet and outlet ports. If using isolation valves, open the valves now. Water should be able to freely flow into the hoses and up to the chiller.

Test the Chiller:

Plug the chiller in. Before turning it on, press the test button. This is used to test
whether the circuit breaker's leakage protection is working properly. After pressing
the test button, the circuit breaker will simulate leakage in the circuit, the device will
trip, and the light will go out. After it trips, press the reset button.



Let's Get Chilly!

Turn the chiller on using the power button located on the display. Water will now start circulating between the chiller and tub. After a few minutes, check if the filter house is full of water. If there is air inside, vent the housing by pressing the red button on top. If there are any leaks, use the white wrench to tighten the filter housing.







Connection Steps


1 Tems and Conditions

Dear Customer.

Thank you for choosing our products! For your convenience, please read the instruction manual carefuly and follow the steps in the instruction manual.

2 Wi-FiStatus identification description





The Wi-Fi status mark is the Wi-Fi icon in the upper right comer of the display panel, which is used to indicate the W-ficonnection status. Please pay attention to the status of the icon when configuring the network to complete the network configuration quickly. The icon status is as follows:

Icon Status	Wi-Fi Status		
Go out	Wi-Fi is initializing or the Wi-Fi module is faulty		
Flash Mob (2Hz)	Wi-Fi is in distribution network status		
Slow Flash (0.5Hz)	Wi-Fi is in distribution network status		
Always On	Connected to cloud platform		

3 Wi-Fi reset

Steps to reset:

- 1) After the controller is powered on, wait for Wi-Fi to complete initialization (that is, Wi-Fi chip triggering),
- 2) In the unlocked state, press and hold the (\equiv) key and (-) key for 6 seconds;
- 3) Within 15 seconds, if the Wi-Fi chip enters the flashing state, the Wi-Fi reset is successful: otherwise, the reset fails and you need to perform a button reset again or perform a power-off restart.

The Wi-Fi reset function is required in the following situations:

- 1) Due to the unstable Wi-Fi environment, it may happen that the device is not added successfully but the Wi-Finetwork configuration has been completed. At this time, it is necessary to reset the Wi-Fi and add the network configuration again;
- 2) After device transfer (change of device owner), the device will be automatically deleted after Wi-Fi reset.

4 Download APP

Use your mobile phone to scan the QR code to download the APP, complete registration and log in. Also allow all access to this app for the best experience.





5 Mobile phone connection Wi-Fi

Make sure that the mobile phone and the device to be connected are in the same Wi-Fi environment. Select the 2.4 GHz Wi-Fi network on the mobile phone and enter the password to connect the mobile phone to WIFI.

6 Add Device


- 1) Tum on the mobile phone Wi-Fi and Bluetooth, and enable location access, please make sure that the mobile phone Wi-Fi and Bluetooth are both turned on to obtain the best network configuration test;
- 2) Open the "Huilian smart" APP, on the mobile phone, and select "Home" in the bottom navigation bar:
- 3) Click the "+" button in the upperright corner of the home page, or click the "Add Device" button in the center of the home page to enter the device adding interface;



4) in the device adding interface, please try to add the device in one of the following ways;

A. Automatic device discovery

The phone will automatically discover available devices nearby. After discovering the device, follow the instructions in the figure below to complete the subsequent network configuration operations.



B、 Scan Code to Configure Network


Click the "Scan" icon in the upper right comer of the device adding interface, put the device network QR code into the box to automatically scan, and follow the steps below to complete the device adding operation.

*Note 1: If you have checked and confirmed that the WiFl status of the device is correct, under the step of "Reset the device", please directly check "Confirm the WiFl status" And click the "Next' button to directly configure the network without the need to reset the device.












7 Add Device

Please scan the "Tuya Smart"code to download the software first, connect to my device and follow the following picture to operate. Click Ice Bath Chiller to enter the machine operation boot page, click Power to switch on and off, click Mode to switch refrigeration/heating, return to the main page, click Scene and then click Create Scene, and then click Schedule to select the time to start refrigeration/heating.









⚠ Cleaning and Maintenance

- 1) After every time use, the internal water of the machine needs to be drained, drain the residual water from the water inlet hole by tilting it, especially in winter, after each time use, it must be drained to prevent the internal water storage from being frozen and cracked.
- 2) The filter element needs to be cleaned and replaced in time.
- 3) The continuous use cycle every 7 days 24 hours requires a period of rest for the chiller.

⚠ WARNING

1)Risk of electric shock,can couse injury or death. 2)Disconnect all remote electric power supplies before servicing. 3)Use on single outlet circuit only. 4)Suitable for commercial or industrialuse only. 5)Thermally protected.

FREEZE WARNING

To avoid damage ,do not place the device that has not been drained of water in a place where the ambient temperature is below freezing.